



Welcome to the SMART Notebook™ 11.2 collaborative learning software tutorial



Review features and get started quickly.

To access this tutorial later, go to



Introducing SMART Notebook 11.2


SMART Notebook software is now faster and better than ever, with an intuitive SMART Ink™ experience and support for more operating systems.



New features in SMART Notebook 11.2



Toggle the zoom level

Switch quickly between the two most common zoom levels, Entire Page and Page Width, by adding this button to your toolbar.



This button is also available on the Full Screen toolbar.

[How to customize your toolbar](#)




Change the default page background color

You can change the default page background color in SMART Notebook Preferences.

[How to edit your Preferences](#)

New features in SMART Notebook 11.2



Turn off Extend Page


Prevent your pages from becoming longer by turning off Extend Page.

Access this option from **View > Extend Page**.

Customize ink fade times

You can type in a custom value for ink fade time.

Remember to press **Save Tool Properties** to save your changes as a default ink style on the toolbar.



Write and draw

Pick up a pen and write

Press a pen color button on the pen tray to change the pen color.

Writing on your SMART Board® interactive whiteboard



On-screen keyboard

Press the **Keyboard** button to launch the on-screen keyboard.



Right-click

To make your next touch a right click, press the **Right-Click** button on the pen tray.

Adaptive toolbar


The toolbar provides shortcuts to commonly used actions, tools and properties. When you use the Select tool to select an object in the work area, its properties appear to the right of the tools group.

Press to reveal




Remember

You can still find additional properties in the Properties tab and in the object's drop-down menu.




Improved toolbar customization

Customize the toolbar so that the buttons you use frequently are only one click away.



Pages




See and sort your pages

Use the **Page Sorter** tab to jump to a page by selecting its thumbnail, or reorganize your pages by dragging them into a different order.

Reset Page

Easily reset your page to its **last saved state**, without reopening your lesson file.



Objects

Resize and rotate

Press the leaf to select.

To rotate, use the green handle.

To resize, use the white handle.


Move objects

Press the leaf and drag it to move it around the page.



Remember

To select an object, switch back to Select mode by putting down the pen and then pressing the **Select** icon.



Text objects

Add text

Click the **Text** button on the toolbar, and then click the work area to create a text box. Start typing.

You can format text using the buttons in the toolbar or the options in the Properties tab or the Format menu.

Edit text

Double-click the text box to edit text.

Resizing the text box

Drag the white handle to adjust the length of the text box and reflow the text inside.

Press to reveal



Try it here! Double-click the text to the left and use the white handle to adjust the text box.



Gallery content



Find content in the Gallery

Find images, videos, sound files, interactive activities, backgrounds and SMART Notebook pages in the Gallery. Just drag and drop to add them to your page.


Add interactivity with the Lesson Activity Toolkit

The Gallery tab also contains templates to help you create your own activities and engage your students with interaction.



Notebook Gallery 2.0 Beta


Test-drive the Notebook Gallery 2.0 Beta and search both online and offline Gallery resources with ease.



Click here
to download


Click the link in the Gallery to visit the **Notebook Gallery 2.0 Beta** channel, where you can learn more about the beta program and how to participate.

Preview



Sound recorder

Record a short sound clip to attach to an object on the page.



Activity Builder

Create interactive lesson activities easily by using the Activity Builder. To start, click the **Add-ons** tab, and then click the **Activity Builder** thumbnail.

Try it




What do horses eat?

Drag and drop foods over the horse to feed it.




Use it in your class today



Need some inspiration? There are many more activity examples in the **Gallery**.

Browser

Browse the Internet without leaving your SMART Notebook file.



Press to reveal



SMART Notebook Internet browser

Browse to any web page within SMART Notebook collaborative learning software.



To see the same web page every time you open the file, press **Pin the Page**.



To return to that page, press **Go Back to Pinned Page**.



Preferences


SMART Notebook Preferences gives you detailed control over your user experience.

Press to reveal



The customizable settings include the following:

- Changing the default page background color.
- Enabling or disabling the shake gesture and the press-and-hold gesture.
- Enabling or disabling hardware acceleration (disable it if your content doesn't display correctly and SMART Notebook software isn't responding).
- Changing the measurement tools' color.
- Adding or removing cell padding in tables.



Access SMART Notebook Preferences from **Edit > Preferences (Windows)** or **Notebook > Preferences (Mac)**.

Download lessons

Download teacher-created lessons from the SMART Exchange™ website

Search by subject and grade. See what other teachers are trying and loving. Download and modify lessons to suit your teaching style.

SMART Exchange
Find Lesson Plans for Your SMART Board and Connect with Teachers

Sign In | Join for free! | United States

My cart

Search | Share a Resource | Standards-Aligned | Community | Training

Search All Resources
Lessons, images and more.

Browse by:

Subject(s)	Grade(s)	File Type
Art and Design	Citizenship	Cross-curricular
English Language Arts	Geography	Health and Physical Education
ICT	Library and Informational Science	Mathematics
Music	Other	Religion
Social Studies	Special Education	Science

Top Downloads (more)

- The Mitten SMART Notebook lesson
- 100 days of school SMART Notebook lesson
- Contractions SMART Notebook lesson
- Jeopardy Template for SMART Response SMART Notebook lesson

Featured Premium resources (more)


- Geometry-Exterior Angles of a Polygon SMART Notebook lesson Saddleback Educational Publishing Price USD 5.00
- Spinner Game Gr. PK-2: Algebra



exchange.smarttech.com

Open the SMART Exchange website in your web browser or click the toolbar icon to go there directly.

SMART Board interactive whiteboard

On the following pages, features with this  symbol are available only on SMART Board 800 series interactive whiteboards or certain other SMART hardware products.

Refer to your interactive product's specifications (available from smarttech.com/support) to determine which features it supports.



For additional resources related to your SMART hardware product, visit smarttech.com/training.

Gestures

Click the buttons to view the gestures.



Using object awareness

Work more naturally

The interactive whiteboard's cameras detect the size of your touch and assign different tools accordingly. This enables you to use your finger or pen to write or select, and your palm or fist to erase.

Click the box below to view object awareness in action.



Use the pen to write, your finger to drag and your palm to erase.

Try it here 

A video has been created to further explain the concept of object awareness and touch recognition here: <http://youtu.be/IBMdi1XM9mc>



Lockable pen option

Play the video file to view the gesture.

If you want to use your SMART Board interactive whiteboard with a rolled up sock, Koosh® ball, tennis ball or pointer, enable the Lockable pen option.



Press and hold a pen color button until it flashes. This locks the interactive whiteboard so you can use any tool, not just your finger or pen, with the interactive whiteboard. Use your tool of choice to write, or press any toolbar tool to change the tool's function.

Press another pen color button to disable the Lockable pen option and go back to using your pen, finger and palm.



Explore other SMART products

Click the products below to learn what's new and more!



SMART Ink

[Introducing SMART Ink!](#)



SMART Notebook Math Tools



SMART Response interactive response software

[What's new in SMART Response 2013](#)



SMART Sync™ classroom management software




SMART Document Camera™



SMART Table® collaborative learning center

Now try it yourself



Start exploring and creating.

For additional help, tutorials or information on training sessions, use the Help menu or go to smarttech.com/training.

Attachments

Tutorial for SMART Response 2013.notebook